

SPORTS REBOUNDER

Assembly, Installation
& Use Instructions

The information in this document is subject to change without notice.
© Copyright Springfree® Trampoline Inc. 2005, 2021. All rights reserved.
766602

 Treat any loaded rod with caution until you are sure it is properly installed or uninstalled. Keep face clear of loaded rods. An improperly installed rod could release and cause facial injury or blindness.

 Do not hold onto, or place fingers between the rods while someone is jumping on the trampoline.

 Entrapment and choking hazard possible for children under 6 years of age.

 Take extra precautions while jumping on the trampoline with a ball as it may interfere with or cause the jumper to fall awkwardly. Do not attempt to jump on the ball as this may cause serious injury.


 Never remove a net rod from its net rod pocket or disengage (unlock) the metal joiner while the net rod is under tension.

WARNING

Read the warnings on this page and those contained in the User Guide before you assemble and use this product.


- Use only with mature, knowledgeable supervision. Enforce all safety rules and be familiar with the information in the User Guide.
 - Two people are recommended for assembly.
 - Do not hang, kick, or climb on the Sports Rebounder and do not allow users to intentionally bounce towards or off the Sports Rebounder, as this can result in serious injury or could damage your trampoline.
 - Do not wear jewellery or drawstrings/cords that can catch on the netting and create a strangulation hazard.
 - During play, keep players face away from the Sports Rebounder. Serious injury can occur if teeth/face come in contact with the net.
 - Do not allow a child or other person under the trampoline to retrieve an errant ball while the trampoline is in use.
 - Do not use the Sports Rebounder as a springboard to other objects.
 - Avoid contacting the net with any sporting equipment other than a ball.
- Maintain a safe clearance around and above your net. When orienting your net, consider the surrounding area. Athletes are responsible for injury or damage caused by a wayward ball.
 - Keep small children away from the trampoline while others are bouncing on it because the edge can move in and out vigorously. There is potential for injury if the bouncer lands heavily on or near the edge.
 - Do not hit, kick or throw weighted balls into the Sports Rebounder while someone is using the trampoline and do not try to intentionally strike another person while using the Sports Rebounder, as this can result in serious injury.
 - To prevent tripping, stubbing your toe, or damage to the trampoline, ensure the pegs are installed to their full depth.
 - Take extra precaution around the Sports Rebounder when mowing the lawn.

 If you encounter any issues during assembly or if you believe your product has a manufacturing fault or defect, visit www.springfreetrampoline.com to find your nearest Springfree Trampoline service center. If you made your purchase at a store, contact Springfree Trampoline first, before returning your product.



 **WARNING** - When choosing the location of the Sports Rebounder on your trampoline, take into consideration ball over-throws and safe and easy retrieval.

 **NOTE** - The Sports Rebounder is only for use on O77, O92, S113, and S155 trampoline models and can only be installed in the areas shown.



 **NOTE** - Do not assemble the Sports Rebounder on the same "mounting rods" as your FlexrHoop.


- Remove all the white c-clips located on the net rod sockets. Carefully lift the bottom end of the net rods out of the net rod sockets and lower the net.
- Select two adjoining net rods. These will be the "mounting rods" where you will locate your Sports Rebounder on the trampoline. These mounting rods will support the Sports Rebounder.
- Remove the two mounting net rods from the net rod pockets.




- Slide the two mounting rods through the pockets on either side of the Sports Rebounder.
- Be sure that you orient your Sports Rebounder properly. The Springfree logo should be facing away from the trampoline.



- Center the logo between the two mounting rods and carefully loop the strap over the top edge of your trampoline net and then fasten to snaps on the back of the Sports Rebounder.
- Starting with the "mounting rods," reinsert the net rods into the net rod sockets on the trampoline frame and refasten the c-clips.



- Stretch out the bottom section of the net to your desired angle and tension.
- Use a rubber mallet to hammer the pegs through the loops into the ground at either corner of the net. Ensure both pegs are installed to their full depth.



- Find the location on the back of the net where you want your target installed. Note that the target should be fastened behind the hitting surface of your net.
- Starting in one of the top corners, fasten the Velcro strap through the netting. After it is secure, fasten the strap in the other top corner and then in the middle.
- Allow the target to fall to its natural position, then fasten the bottom Velcro straps, starting in one corner, then the opposite corner, and finishing in the middle.
- Finish by attaching the two side straps.

1 YEAR WARRANTY

All Springfree Trampoline Accessories are covered by a one year warranty, with the exception of the Springfree FlexrBall which has a 3 month warranty. We warrant our products to be free of defects in material and workmanship under normal domestic use and service conditions which does not include general wear and tear, burns, cuts or snags. For more details, visit: www.springfreetrampoline.com/warranty-information